



Block Packaging Instructions

1. Strip Block of all bolt on / bolt in items except water plugs. Degrease Block and clean, so there's no oil. If block arrives dirty with sensors, and bolt-on items a \$50.00 Additional Charge will be made.
2. Use 18x18x15 Heavy Duty Box for shipping. Cut 2 pieces of plywood to fit box opening. [17-1/4 x 17-1/4]
3. Place 1 piece of wood in bottom of carton.
4. Place 3 inches of bubble wrap on top of wood
5. Place block on packing - crank end against a piece of wood.
6. Pack bubble wrap firmly between block and carton with 3 inches on top.
7. Place 2nd piece of plywood on top.
8. Pack bubble wrap on top so there is no movement when box is sealed.
9. Please Print out our [Block Sleeving Customer Info Form](#) and put in Box.

DO NOT USE PACKING POPCORN / PEANUTS - It breaks down and doesn't provide any support for the block. It will also get into oil and coolant passages. If this happens we will charge an additional \$25.00 Fee. Please insure your package, We are not responsible for any damage during shipping of your block to us. We will insure your block when it leaves our shop.